



Explosive & Narcotics Trace Detector

TW-NE300

TW-NE300 portable explosive/narcotics trace detector is a narcotics and explosives detection device independently designed and manufactured by TimeWatch. Based on the principle of ion mobility spectrometry, it can accurately detect particles or vapor of trace amounts of explosives and narcotics, and give the ingredient names. Due to the superior technical features and specifications including fast response, high precision, low power consumption, easy to operate and maintain, the detector is widely used for dangerous goods detection in airports, ports, customs checkpoints, border crossings, and crowd-gathered places, or used as a tool for forensic evidence examination and identification.



(+91)-11-41916615
+91-95999-53923



D-162, Okhla Industrial Area
Phase I, New Delhi, 110020



sales@timewatchindia.com
www.timewatchindia.com

Specification

General Specifications

Weight	<4.0kg
Size	290mm(L) x 170mm(W)x145mm(H)
Battery	Working time > 3 hours, Standby time > 12 hours
Power adapter	Adapter: AC110V/220V AC, 50~60Hz Output: 19.5V Charger: AC110V/220VAC, 50~60Hz

Performance Parameter

Explosables	TNT, Hessian, Taina, Nitro-glycerine, Ammonium Nitrate, Black Powder, Dinitrotoluene, Tetra, Oktojin, Gina, TATP, HMTD, C4, Semtin, etc. And earth explosives, etc., and add new samples as needed.
Checkable drugs	Hydrochloric acid cocaine, heroin hydrochloride, tetrahydrocannabinol, methamphetamine (ice), ketamine hydrochloride (K powder), morphine hydrochloride, opioid, ecstasy, dulantin and other common drugs on the market, and can add new samples as needed.
Sensitivity	pg level
Analysis time	≤3s
Start Time	< 5 min
False alarm rate	≤ 1%
The detection rate	≥ 99%
Restore the alarm time	<15s

System Function

Language	English
Database	Open database, ready to update.
Sampling	Trace particle adsorption sampling, test paper wiping sampling.
Detector type	Detect drugs and explosives.
Mixture	With main component detection and mixture component.
Alarm mode	It has sound, light, character light alarm display, alarm mode selection switch, optional sound and light alarm, or hidden alarm mode that does not cause panic.



Environmental parameter	
Working/storage temperature	-20°C~60°C
Working/storage temperature	<95%
Working pressure	60kPa~106kPa

Product Highlight

Dual-mode Settings

The instrument combine the positive and negative two modes inside, which are respectively for the detection of explosives and narcotics.

One-touch detection

One-touch detection, easy to operate

Precise Detection



Based on Ion mobility spectrometry technology, in practice, the instrument don't need touch directly the dangerous target from the package to make a test. Target particles can be collected on clean and new traps by hand-wiping suspect with the trap, to facilitate a simple and precise detection.

Accurate Identification



The instrument is able to accurately identify the name and ingredient name of dangerous materials.



Detection spectrum



Detection spectrum



Head Office : D-162, Okhla Industrial Area Phase I,
New Delhi, 110020.

Regional Office : Mumbai, Bengaluru, Ahmedabad,
Chennai, Kolkata.

International Office : Dubai

Disclaimer : All pictures shown are for illustration purposes only. The actual product and color may vary due to product enhancement. The brief specification is mentioned and may change without prior notice. Please consult us before placing any order.

Phone : +91-95999-53923

Sales : sales@timewatchindia.com

Support : helpdesk@timewatchindia.com